



**Please Note: This sensor *must* be used with a Galvanic Isolation Amplifier - See G005 sheet for Output options.**