



USER MANUAL | DS-40





Table of Contents

1.	Preface 1.1 Version 2.0: March 2020 1.2 Applicable documents	2 2 2
2.	ESD Protection	2
3.	Product overview 2 3.1 Overview 2 3.2 Installation flow chart 2 3.3 Encoder mounting 2	2-3 2 2 2
4.	Unpacking 4.1 Standard order	3 3
5.	Electrical interconnection 5.1 Absolute position over SSi or BiSS-C 5.2 Setup mode over NCP 5.3 Electrical connection and grounding	4 4 4
6.	Software installation6.1 Minimum requirements6.2 Installing the software	4 4
7.	Mounting verification7.1Starting the Encoder Explorer7.2Mechanical installation verification	5 5 5
8.	Calibration 8.1 Offset calibration 8.2 CAA calibration 8.3 Setting the encoder zero point 8.4 Jitter test	5-7 5 6 7
9.	Operational mode 9.1 SSi / BiSS	7 7
10.	Mechanical drawing	8





1. Preface

- 1.1 Version 1.0: February 2020
- 1.2 Applicable documents
- DS-40 electric encoder data sheet

2. ESD protection

As usual for electronic circuits, during product handling do not touch electronic circuits, wires, connecters or sensors without suitable ESD protection. The Integrator / operator shall use ESD equipment to avoid the risk of circuit damage.



3. Product overview

3.1 Overview

The DS-40 absolute position Electric Encoder[™] is a revolutionary position sensor originally developed for harsh environment critical applications. Currently it performs in a broad range of applications, including defense, homeland security, aerospace, and medical and industrial automation.

The Electric Encoder[™] non-contact technology relies on an interaction between the measured displacement and a space/ time modulated electric field.

The DS-40 Electric EncoderTM is semi-modular, i.e., its rotor and stator are separate, with the stator securely housing the rotor.

- (1) Encoder stator
- (2) Encoder rotor
- (3) Encoder mounting ears
- (4) Encoder cable





3.2 Installation flow chart







3.3 Encoder mounting





The encoder rotor (2) attaches to the host shaft by pressing it against a dedicated shoulder (b). A screw and washer or circular spring and washer at the end of the shoulder maintain pressure. The encoder stator (1) is centered by circumferential step (a) and attached to the host stator (c) using three M2 screws, recommended torque of 0.3Nm.

Note: DO NOT use screw locking materials contain Cyanoacrylate which interact aggressively with the sensor body made of Ultem.

Encoder stator / Rotor relative position

The rotor is floating therefore, for proper relative axial mounting, distance "H" between the shaft shoulder (b) and stator mounting recess (a) should be ± 0.05 mm nominal. For ease of mechanical mounting compensation by rotor shims, the recommended distance is ± 0.05 mm.

The optimal recommended amplitude values are middle of the range according to those shown in the Encoder Explorer software and vary according to the encoder type.



The DS-40 amplitudes compensation:

Mechanicaly compensate by using 50 um shims below the rotor (available as DS40-R-00 kit).

Verify proper rotor mounting with the Encoder Explorer tools "Signal analyzer" or "Mechanical installation verification."



Note: for more information please read paragraph 6

4. Unpacking

4.1 Standard order

The package of the standard DS-40 contains the encoder with 250mm shildedd cable AWG30.

Optional accessories:

- (1) DS-40-R-00 Kit, Rotor mounting shims: x10 stainless steel 50um thick rotor mounting shims.
- (2) MA-DS40-004 Kit, end of stepped shaft installation kit (3 screw M2x4, washer).
- (3) MA-DS40-004 Kit, end of smooth shaft installation kit (3 screw M2x4, spring, C-ring).
- (4) EAPK008 Kit, encoder mounting screws (3 screws M2x6).
- (5) CNV-0003 RS-422 to USB converter (with USB internal 5V power supply path).
- (6) NanoMIC-KIT-01, RS-422 to USB converter with full digital interface for both NCP & high speed SSI/Biss and AqB (with USB internal 5V power supply path).
- (7) DKIT-DS-40-SF, Mounted SSi encoder on rotary jig, RS-422 to USB converter and cables.
- (8) DKIT-DS-40-IF, Mounted BiSS encoder on rotary jig, RS-422 to USB converter and cables.





5. Electrical interconnection

This chapter reviews the steps required to electrically connect the encoder with digital interface (SSi or BiSS-C).

Connecting the encoder

The encoder has two operational modes:

5.1 Absolute position over SSi or BiSS-C:

This is the power-up default mode



SSi / BiSS interface wires color code

Clock +	Grey	Clask
Clock -	Blue	LIUCK
Data -	Yellow	Data
Data +	Green	Dala
GND	Black	Ground
+5V	Red	Power supply

5.2 Setup mode over NCP (Netzer Communication Protocol)

This service mode provides access via USB to a PC running Netzer Encoder Explorer application (on MS Windows 7/10). Communication is via Netzer Communication Protocol (NCP) over RS-422 using the same set of wires.

Use the following pin assignment to connect the encoder to a 9-pin D-type connector to the RS-422/USB converter CNV-0003 or the NanoMIC.

Electric encoder interface, D Type 9 pin Female

Description	Color	Function	Pin No
SSi Clock / NCP	Gray	Clock / RX +	2
RX	Blue	Clock / RX -	1
	Yellow	Data / TX -	4
SSI Dala / INCP TX	Green	Data / TX +	3
Ground	Black	GND	5
Power supply	Red	+5V	8

5.3 Electrical connection and grounding

The encoder does NOT come with specified cable and connector, however, do observe grounding consideration:

[1] The cable shield does not connect to the power supply return line.

[2] Ground the host shaft to avoid interference from the host system, which could result in encoder internal noise.

Note: 4.75 to 5.25 VDC power supply required

6. Software installation

The Electric Encoder Explorer (EEE) software:

- Verifies Mechanical Mounting Correctness
- Offsets Calibration
- Sets up general and signal analysis

This chapter reviews the steps associated with installing the EEE software application.

6.1 Minimum requirements

- Operating system: MS windows 7/10, (32 / 64 bit)
- Memory: 4MB minimum
- Communication ports: USB 2
- Windows .NET Framework, V4 minimum

6.2 Installing the software

- Run the Electric Encoder[™] Explorer file found on Netzer website: <u>Encoder Explorer</u> <u>Software Tools</u>
- After the installation you will see Electric Encoder Explorer software icon on the computer desktop.
- Click on the Electric Encoder Explorer software icon to start.



Connect Netzer encoder to the converter, connect the converter to the computer and run the Electric Encoder Explorer Software Tool







7. Mounting verification

7.1 Starting the Encoder Explorer

Make sure to complete the following tasks successfully:

- Mechanical Mounting
- **Flectrical Connection**
- Connecting Encoder for Calibration
- Encoder Explore Software Installation

Run the Electric Encoder Explorer tool (EEE)

Ensure proper communication with the encoder: (Setup mode by defoult).

- (a) The status bar indicates successful communication.
- (b) Encoder data displays in the encoder data area. (CAT No., Serial No.)
- (c) The position dial display responds to shaft rotation.



-SO

direction selection before calibration to ensure optimal performance. It is also reccomended to observe the

instaletion at the [Tools - Signal Analizer] window.

7.2 Mechanical installation verification

The Mechanical Installation Verification provides a procedure that will ensure proper mechanical mounting by collecting raw data of the fine and coarse channels during rotation.

(d) Select [Mechanical Mounting Verification] on the main screen.



(e) Select [Start] to initiate the data collection.

(f) Rotate the shaft in order to collect the fine and coarse channels data.



(g) At the end of a successful verification, the SW will show "Correct Mechanical Installation."

	Mechanical installation status Correct n	nechanical installati	on o
Les l	Ohered select	Gançies per channel 300 -	Total time (sec) 25:00
Fine Cosine (mV)			
Durtur			Conta

(h) If the SW indicates "Incorrect Mechanical Installation," correct the mechanical position of the rotor, as presented in paragraph 3.3 - "Rotor Relative Position."



8. Calibration

New feature

Auto-Calibration option enabled. Refer to document: <u>Auto-calibration-</u> feature-user-manual-V01

8.1 Offset calibration

For optimal performance of the Electric Encoders, the inevitable DC offset of the sine and cosine signals must be compensated over the operational sector.

After successfully completing the Mounting Verification procedure:

(a) Select [Calibration] on the main screen.









FA offsets calibration

(b) Start the data acquisition while rotating the shaft.

The progress bar (c) indicates the collection progress.

Rotate the axis consistently during data collection-covering the working sector of the application end to end-by default the procedure collects 500 points over 75 seconds. Rotation speed is not a parameter during data collection. Data collection indication shows for the fine/coarse channels, a clear "thin" circle appears in the center (d) (e) with some offset.



Offset compensated fine / Corse channel





8.2 CAA calibration

The following calibration aligns the coarse/ fine channel by collecting data from each point of both channels.

Select [Continue to CAA Calibration]

In the CAA angle calibration window, select the relevant option button from the measurement range options (a):

- Full mechanical rotation shaft movement is over contentious recommended.
- Limited section define operation of the shaft in a limited angle defined by degrees in case of <10deg
- Free sampling modes define the number of calibration points in the total number of points in the text box. The system displays the recommended number of points by default. Collect a minimum of nine points over the working sector.
- Click the [Start Calibration] button (b)
- The status (c) indicates the next required operation; the shaft movement status; the current position, and the next target position to which the encoder should be rotated.
- Rotate the shaft/encoder to the next position and click the [Continue] button (c)

 the shaft should be in STAND STILL during the data collection. Follow the indication/ interactions during the cyclic process for positioning the shaft --> stand still --> reading calculation.
- Repeat the above step for all defined points. Finish (d)
- Click the [Save and Continue] button (e).

The last step saves the offsets CAA parameters, completing the calibration process.

Measurement Full mechan Limited sec Free sample	range nical rotation tion [degrees] 45 = ing mode	Total number of points	
Shaft moveme	ent status		
No shaft move during samplin	ement was detected ng.	Start calibration b	
Calibration pro	opess control		
Continue	c	Stop sampling 0.00 degrees 0.00 degrees.	
Curre Next s	nt incremental position sample position:		
Results [electr	rical degrees] Before calibration	After calibration	
CAA	-8.70	N/A	
MAA		N/A	
e Save and	I continue	Discard d	
Press Start to begin.			

52







8.3 Setting the encoder zero point

The zero position can be defined anywhere in the working sector. Rotate the shaft to the desired zero mechanical position.

Go into "Calibration" button at the top menu bar, press "Set UZP".

Select "Set Current Position" as zero by using the relevant option, and click [Finish].

Set User Zero Position	X	
User Zero Position		
Set current position as	0.000 🚔 degrees	
Set current position as	0 🛓 counts	
Set specific UZP to	0.000 A degrees	
Set specific UZP to	0 🛓 counts	
Finish	Discard	

Fie Calbration Tools He Netzer Setup Mode ncoder data 0.000 ATH DS-58-5G-Jution 262144 CPR (18 h) 0 000000000 EW 4.0.7 Genal amplitude (mV 0 125 150 178 400 425 450 478 500 5

8.4 Jitter test

Perform a jitter test to evaluate the quality of the installation; the jitter test presents the reading statistics of absolute position readings (counts) over time. Common jitter should be up +/- 3 counts; higher jitter may indicate system noise.

er fest				
Ormer Abacken Fostion Min Corrent Degree 0.000 0.000 Course 0 0 Main [counts] ± 05,55.5 Taning and Sampling Time between disk requests [mS4c] Ancust of samples Mode Benchalon Fine Channel resol Minde AP resolution AP resolution	Max 359 597 131071 10 2 500 2 4000 2 4000 2 208 4000 32788 131072	500 0 400 0 400 0 300 0 400 0 400000000	AP Jitter histograf	n
Start Results AP returb AP atter (Segreen) ± 50027 AP atter (Segreen) ± 50007 AP atter (Segreen) ± 50007 AP macrosom (1990) AP macrosom (1990) AP macrosom (1990) (1990)	View log	в Алини мон 100 по по 100 по по по по по по по по 100 по по по по по по по 100 по по по по по по по 100 по по по по по по по по по 100 по по по по по по по по по по 100 по по 100 по	AP in counts	13167

In case the reading data (blue dots) are not evenly distributed on a thin circle, you may experience "noise" in your installation (check shaft/stator grounding).



Error! Fine Roundness factor was 78.07% which is less then 85%!

9. Operational Mode

9.1 SSi / BiSS

Operational mode indication of the SSi / BiSS Encoder interface available by using the NanoMIC.

For more information read about NanoMIC on Netzer website

The operational mode presents the "real" SSi / BiSS interface with 1MHz clock rate.

Protocol SSi



Protocol BiSS

×

OK







ABSOLUTE POSITION ROTARY ELECTRIC ENCODER™



USER MANUAL

10. Mechanical drawings



ICD